


DELTADORE Tydom 140 – Tydom 141 - TLX2 - TLX4Programming of your new remote control :

1. Approach your receiver. It is located next to your motor.
2. Open the casing of your receiver.
3. Press the ON and OFF buttons on your already-programmed remote control for 5 seconds at the same time.
4. Press the ON button on your already-programmed remote control for 5 seconds (1).
5. Press the ON button on your new remote control. Keep it pressed down. The receiver emits a beep (2). Let the button go.
6. Wait 10 seconds.
7. Your new remote control is programmed.