


## Programming Manual

### GENIUS 252 - 254



#### Programming of your new remote control:

1. Open the casing of your receiver. It is located next to your motor.
2. On the receiver circuit board, press the programming button « MEMO » (P2). Keep it pressed down. The LED light L1 on the receiver blinks. Let the button go.
3. Press a button on your new remote control. Let it go.
4. The LED light on the receiver remains lit constantly and then turns off.
5. Wait 10 seconds.
6. Your new remote control is programmed.