


HOMENTRY H54332 - CHAMBERLAIN 54332

1. Look for the programming buttons on your receiver. They are found on your motor.
2. Press the programming button S on the receiver circuit board. The receiver LED number 1 illuminates for 10 seconds. Let the button go.
3. In the next ten seconds, press a button on your new remote control twice. The LED on the receiver goes out.
4. Your new remote control is programmed.