



Programming Manual

NICE Moon MOTX-R




Programming of your new keyboard with a FLOX-R receiver




1. Open the casing of your receiver. It is located next to your motor.
2. On the receiver circuit board, press the programming button (P1). Keep it pressed down. The LED light on the receiver illuminates. Let the button go.
3. Type « 11 » on the keyboard. Press the button «  ». Keep it pressed down. The LED light on the receiver turns off. Let the button go.
4. Press the button «  » again for 2 seconds. The LED light on the receiver blinks three times.
5. Wait 10 seconds.
6. Your keyboard is programmed.

Programming of your keyboard with an SMXI receiver in MODE I (general)


1. Open the casing of your receiver. It is located next to your motor.
2. On the receiver circuit board, press the programming button. Keep it pressed down. The LED light on the receiver illuminates. Let the button go.
3. Type « 11 » on the keyboard. Press the button «  » for 3 seconds.
4. The LED light on the receiver blinks three times and then remains lit constantly.
5. Wait 10 seconds. The LED light turns off.
6. Your keyboard is programmed.

Programming of your keyboard with an SMXI receiver in MODE II (personalized)

Programming of the first channel:

1. Open the casing of your receiver. It is located next to your motor.
2. On the receiver circuit board, press the programming button the number of times corresponding to the operation you wish to perform:
 - Once : Step by step
 - Twice : Partial opening
 - Three times : Open/Stop
 - Four times : Close/Stop
3. The LED light on the receiver blinks the same number of times.
4. Type "22" on your keyboard. Press the button «  » for 3 seconds.
5. The LED light on the receiver blinks three times and then remains lit constantly.
6. Wait 10 seconds. The LED light on the receiver turns off.
7. The first channel is programmed.

Programming of the second channel:

1. On the receiver circuit board, press the programming button the number of times corresponding to the operation you wish to perform:
 - Once : Step by step
 - Twice : Partial opening
 - Three times : Open/Stop
 - Four times : Close/Stop
2. The LED light on the receiver blinks the same number of times.
3. Type « 22 » on your keyboard. Press the button «  » for 3 seconds.
4. The LED light on the receiver blinks three times and then remains lit constantly.
5. Wait 10 seconds. The LED light on the receiver turns off.
6. The second channel is programmed
7. Your keyboard is programmed.